

Label Printer



QUICK USER GUIDE

Compatible for AQ00/AQ20/Q00/Q20

Shanghai PUQU Marking Equipment Co.,Ltc 2021.Sep









SAFFTY INSTRUCTIONS



THIS PRODUCT IS NOT EQUIPPED WITH A STANDARD POWER ADAPTER. PLEASE BE SURE TO USE 3C CERTIFICATION AND MEET THE STANDARD REQUIREMENTS.

FRONT SIDE

125mm



REVERSE

SIDE



52mm



© CONNECTION MODE
Android & iOS & PC

PRINT SPEED
25-56mm/s

POWER ACCESS
DC5V/1.5A

DOT EACH ROW
384 dot/line

PAPER ROLL DIAMETER
50mm


PRINT WIDTH
48mm

PAPER THICKNESS

PRINT INTERFACE

Bluetooth + USB

BARCODE TYPE
Barcode/QRcode



- 1 Cover opening button
- 2 Left button (Power key/Option)
- Right button (Confirm/Feeding)
- A Display Screen
- USB interface
- 6 Paper storage

🌣 Maintenance Tips

- It is recommended to clean and maintain the print head regularly.



Please do not break the buckle hard, push it down to adjust the size of the paper placement area.

Step 1

Please press on cover opening handle, open the paper storage



Step2

Please push the baffle buckle upward to lock the baffle position



Step2

Please put the paper roll to the left (printing side face to up); slide the haffle to the left



Step4

Please fasten the cover down and press the paper head






Press on right button feeding test







Power Off State

Press the left button long time to turn on the machine, Ring! The display screen lights up to enter the initial state.

Power On State

Press the right button long time to turn off the machine, Ring! The display screen shut down; press the left button to enter the menu mode.

Power On state, (not in the menu mode) press right button to feed the paper.

In Menu Mode

Click on the left button to choose different menu options, the menu options include print darkness; print speed; paper gap, auto feeding and auto power off. No operations for 3 seconds, or press the left button for 3 seconds to exit the menu mode and return to the initial state Click on the right button to cycle through the configuration items of the current option

Initial State

Display Screen



Bluetooth、Paper Storage State、 Battery State、Machine ID

Screen indicator

☐/ ☑ Have paper / No paper

₺/₺ Battery is charging/ charging is full

USB data cable connection transmission

A Cover is opened

Battery is powering

☼ Menu setting

PRECONDITIONS










STEPS OF CONNECTION

© Click on the connection button from the setting interface
or click the print icon in the upper right corner of the home page.







Select printer





app Loading APP



Choose Template







90°

Click Print

(F

180°

PUQU

PUQULABEL.COM



APP Download



PUQU Official Account