PUQU

Label Printer



QUICK USER GUIDE

Compatible for Q1/P1/R1/G1/B1

Huainan Chongqu Electronic Technology Co., Ltd. 2023.Aug










SAFETY WARNING



THIS PRODUCT IS NOT EQUIPPED WITH A STANDARD POWER ADAPTER. PLEASE BE SURE TO USE 3C CERTIFICATION AND MEET THE STANDARD REQUIREMENTS.







CONNECTION MODE

Android & iOS & PC

PRINT SPEED
20-50mm/s

POWER ACCESS
DC 5V/1A

DOT EACH ROW
384 dot/line

PAPER ROLL DIAMETER
38mm

PRINT WIDTH
48mm


D PAPER THICKNESS

PRINT INTERFACE

Bluetooth + USB

BARCODE TYPE
Barcode/QRcode







- 1 Cover opening handle
- 2 Circular button
- (3) Left baffle


(4) Right baffle

- (5) USB interface
- **6** Paper storage

Maintenance Tips

- We recommended you to charge regularly to prevent battery aging if the
- Use a cotton swab dipped in alcohol to wipe the print head and prolong





Step 1

Please gently pull the cover opening handle to open the paper storage



Step2

Please put the paper roll to the right, slide the right baffle to align with the edge (the baffle buckle unlocks upwards)



Step3

Please push down the baffle buckle to lock the position of the baffle



Step4

Please fasten the cover down and press the paper head.









The only button (circular button) for this series of models is located on the bottom half centered

1 Power Off State

Press the button, the indicator light comes on, enter the initial state, and the printer is ready to print.

2 Power On State

Click once to automatically feed one paper

3Power On State

Long press (hold for about 3 seconds or more) to enter the Power Off state, the indicator light off

(4) Power On State

When opening the paper storage, it will sound once and the indicator light will change, when closing the paper storage, it will automatically feed one paper

Note: There may be slight changes following firmware upgrades

PRECONDITIONS









STEPS OF CONNECTION

Click on the connection button from the setting interface
 or click the print icon in the upper right corner of the home page.



Step 1
Select the printer you want to connect



Pairing Bluetooth devices


Bluetooth setting paring request




Step4
the corresponding Bluetooth
device "connected"















PUQULABEL.COM





APP Download

PUQU Official Account

NOTE:

Thank you very much for ordering our PUQU products. In order to better serve our customers, we have a dedicated customer service team to coordinate any issues. If you cannot receive a verification code when registering for QU PRINTING, please contact our customer service representative to register.

The email address is: service.int@pugulabel.com Or pugu1773@hotmail.com